





Mount the t-bracket for the optional keeper grabber with break kit to the side of the platform using the recessed wholes as shown.



Line up the groove on the keeper arm without break with the grove on teh t-bracket and slide up...



...until the bottom roller wheels barely touch the bottom of the rail. Tighten the knob. Adjust roller wheels horizontally to fit the rails. Tighten the bolts to secure.



Mount second t-bracket to the opposite side and slide the arm with the break into place. Secure with knob and adjust roller wheels to fit the rail.



Collapse the spring on the break by pressing the far washer. Swing both arms up and over the rail. Slide the end of the bolt into the opposing arm.



Tighten the knob to engage the break.