

MITCHELL CAMERA RISER

by *Kessler*

INSTALL TO MITCHELL MOUNT

1. Set the Mitchell Camera Riser (MCR) onto the Mitchell Mount while lining up the Position Locking Screw with the cutout.
2. Screw the tie down handle onto the threads on the bottom of the MCR.

INSTALL TO SHUTTLE POD (BOLT ON)

1. Remove the Position Locking Screw and Mitchell tie down assembly from the MCR.
2. Set the MCR onto the Mitchell Mount while lining up the (4) countersunk holes with the (4) 3/8"-16 threaded holes on the top of the Shuttle Pod cart.
3. Screw the (4) 3/8"-16 countersunk screws through the MCR and into the Shuttle Pod cart.



INSTALL TO K-POD (OPTIONAL MOUNT)

1. Remove the Mitchell tie down assembly and install the K-Pod 100mm tie down assembly.
2. Set the MCR on top of the K-Pod's 100mm bowl.
3. Thread the tie down grip onto the stud on the bottom of the MCR with the cup washer in-between.

