



Innovative Tools for Filmmakers

Quick Start: Camera Battery Adapter for Canon 5D Mark II/7D/60D

1) Connect either the 12VDC Power Adapter (that is connected to the 12V battery) or the ORACLE AC Power Supply to the Canon Battery Adapter



2) Insert the Canon Battery Adapter to your camera



3) Be sure to close the battery door of your camera (must be closed to operate)

Note:

Feed the chord through the rubber tab located near the battery door



4) Turn on your camera

Note:

There may be a warning screen on your camera when power on.

This is just to let you know that the camera cannot communicate with the battery adapter or know its remaining charge.

