


MAGPAK BATTERY

by *Kessler*

The MagPack™ Battery is an ultra-portable power solution for Kessler motion control products, specifically designed for Second Shooter. Featuring 3.8Ah @12.6V (48Wh), the battery has been tested running a 3-axis Second Shooter at 50% power for 8+ hours. Using Kessler's Magnalink system, the battery mounts behind the Second Shooter controller to ensure an organized and secure set up.



Use

1. Connect device to the battery via Barrel or USB port.
2. Turn on battery.

Charging

1. Connect charger to the battery and turn ON the battery. A red light will appear on the charger.
2. Once the battery is charged, the LED light on the charger will turn green (approximately 2-3 hours of charge time).
3. Disconnect the battery and turn off.

The battery has a level indicator with 3 green LEDs and 1 red LED. To use, turn the battery on and press the button. This will indicate the amount of charge left on the battery.

If battery is charged, but battery meter does not appear to be accurate, use the battery to completely drain the charge and then charge the battery again. This should reset the battery meter.